

Particles and Processes in Geant4

Vladimir Ivantchenko

CERN, Geneva, Switzerland & Tomsk State University, Russia

Geant4 Advanced Course

28 September 2020



- Geant4 interface to physics
 - Geant4 basic interfaces to physics
 - Geant4 particles
 - Geant4 processes
 - Physics Lists
- Electromagnetic (EM) physics
 - EM physics overview
 - EM physics constructors
 - User interface to EM physics


- The interface of Geant4 kernel to physics is abstract
- Base physics abstract classes are following:
 - The **G4ParticleDefinition** objects shared between threads
 - The **G4VProcess** thread local objects
 - The **G4ProcessManager** thread local interface class
- Configuration of physics is prepared in the **G4VUserPhysicsList** mandatory user class
- These interfaces are stable for ~20 years allowing users to work with different Geant4 versions and providing a basis for new developments
 - Concrete physics is implemented in physics models and cross section classes
 - Alternative models and cross sections are provided in Geant4 libraries
 - A user may be also a developer of a custom particle, process, physics model, or cross section

GEANT4 PARTICLES

- G4ParticleDefinition is the main object keeping static information about particles
 - Name, mass, charge, quantum numbers, decay table....
- “Stable” particles
 - Leptons: e^{\pm} , μ^{\pm} ,
 - Bosons: G4Gamma, G4OpticalPhoton,
 - Geantino is a particle without any interaction
 - “Stable” hadrons: π^{\pm} , K^{\pm} ,
 - Light ions: d, t, ^3He , ^4He
 - G4GenericIon is used to define physics for all other ions
- “Unstable” hadrons normally do not tracked by Geant4 but used internally by hadronic models
 - Quarks, di-quarks, $\rho(770)$, $\omega(783)$...


Split class – case of particle definition

- In Geant4, each particle type has its own dedicated object of G4ParticleDefinition class.
 - Static quantities : mass, charge, life time, decay channels, etc.,
 - To be shared by all threads.
 - Dedicated object of G4ProcessManager : list of physics processes this particular kind of particle undertakes.
 - Physics process object must be thread-local.



GEANT4 PROCESSES

- Processes are classified as:
 - Electromagnetic
 - Hadronic
 - Decay
 - Parameterized
 - Transportation
 -
- Any process has process type and sub-type
 - `const G4String& G4VProcess::GetProcessType();`
 - `G4int G4VProcess::GetSubType();`
 - This method is recommended to be used for MC truth
 - The list of sub-types are only updated with new processes
- Any process may be initialized using virtual methods:
 - **`G4bool IsApplicable(const G4ParticleDefinition &);`**
 - Used to check if a process can handle the given particle type
 - **`void PreparePhysicsTable(const G4ParticleDefinition&);`**
 - **`void BuildPhysicsTable(const G4ParticleDefinition&);`**
 - Used for initialization of internal data of the process before run




- **the standard EM part:** provides a complete set of EM interactions (processes) of charged particles and gammas from 1 keV to \sim PeV
 - Used practically in all kind of Geant4 applications
- **the low energy EM part:** includes special treatments for low energy e-/+, gammas and charged hadrons:
 - more sophisticated approximations valid down to lower energies e.g. more atomic shell structure details
 - some of these processes will be valid down to below keV but some can be used only up to few GeV
- **optical photons: interactions special only for long wavelength photons**
 - processes for reflection/refraction, absorption, wavelength shifting, (special) Rayleigh scattering
 - **G4OpticalPhoton** is the particle type
- Phonon physics is also implemented within Geant4

- Pure hadronic interactions for 0 to 100 TeV
 - elastic, inelastic, capture, fission
- Radioactive decay:
 - both at-rest and in-flight
- Photo-nuclear interaction from ~ 1 MeV up to 100 TeV
- Lepto-nuclear interaction from ~ 100 MeV up to 100 TeV
 - e^+ and e^- induced nuclear reactions
 - muon induced nuclear reactions
- Recently introduced processes of neutrino-nuclear interactions

- decay processes includes:
 - weak decay (leptonic, semi-leptonic decay, radioactive decay of nuclei)
 - electromagnetic decay (π^0 , Σ^0 , etc.)
 - strong decay not included by default
 - they are part of hadronic models
 - may be assigned by a user to a particle
- parameterized process:
 - assigned to **G4LogicalVolume**
 - instead of step-by-step simulation provides hits in the logical volume and list of particles living the volume
 - for example, EM shower generation in a calorimeter based on parameters obtained from averaged events
- transportation process:
 - responsible for propagating a particle through the geometry in electromagnetic or gravitational field
 - needs to be assigned to each “stable” particle

- **G4Track** is the object “pushed” step by step by the tracking :



- Moving by one step is the responsibility of the “stepping”
 - Which is the core engine of the “tracking” machinery
- These moves/steps are defined by physics or by geometry
 - Step length limit is a result of competition of processes
 - Any process may change the **G4Track**, let’s see how
 - **G4Transportation** stops track at the volume boundary

- Abstract class defining the common interface of **all processes** in Geant4:
 - Used by all processes
 - including transportation, etc...
 - Defined in **source/processes/management**
- **Three kinds of actions:**

- **AtRest** actions:

- Decay, e^+ annihilation ...




- **AlongStep** actions:

- To describe continuous (inter)actions, occurring along the path of the particle, like ionisation;

- **PostStep** actions:

- For describing point-like (inter)actions, like decay in flight



- The virtual «**action**» methods are following:
 - **AtRestGetPhysicalInteractionLength()** ,
AtRestDoIt() ;
 - **AlongStepGetPhysicalInteractionLength()** ,
AlongStepDoIt() ;
 - **PostStepGetPhysicalInteractionLength()** ,
PostStepDoIt() ;
- Optional run time virtual methods:
 - **StartTracking(G4Track*)**;
 - Allowing the process preparation for a new G4Track
 - **EndTracking()**;
 - End of given G4Track

- A process can implement **any combination** of the three **AtRest**, **AlongStep** and **PostStep** actions:
 - decay = **AtRest** + **PostStep**
- **If you plan to implement your own process:**
 - A set on intermediate classes exist implementing various combinations of actions:
 - For example:
 - **G4VDiscreteProcess**: only **PostStep** actions
 - **G4VContinuousDiscreteProcess**: **AlongStep** + **PostStep** actions

- It is a **Geant4** kernel class
 - A user should not change it
- **G4ProcessManager** maintains three vectors of actions :
 - One for the **AtRest** methods of the particle;
 - One for the **AlongStep** ones;
 - And one for the **PostStep** actions.
- Note, that the ordering of processes provided by/to the **G4ProcessManager** vectors is relevant and used by the stepping
 - There are few critical points you should be aware of
 - Multiple scattering can shift end point of a step
 - Scintillation, Cerenkov and some other processes assuming that step and energy deposition at the step are defined

PHYSICS LISTS

- Physics List is an object that is responsible to:
 - specify all the particles that will be used in the simulation application
 - together with the list of physics processes assigned to each individual particles
- One out of the 3 mandatory objects that the user needs to provide to the G4RunManager in case of all Geant4 applications:
 - it provides the information when, how and what set of physics needs to be invoked
- Provides a very flexible way to set up the physics environment:
 - the user can chose and specify the particles that they want to be used
 - the user can chose the physics (processes) to assign to each particle

- Current recommendation to use Physics List via inheritance from **G4VModularPhysicsList** which derives from **G4VUserPhysicsList**
- Main public methods:
 - G4VModularPhysicsList::RegisterPhysics(G4VPhysicsConstructor*)
 - Addition of physics constructor
 - G4VModularPhysicsList::ReplacePhysics(G4VPhysicsConstructor*)
 - Replacement of the same type of physics constructor
- Constructor types:
 - Electromagnetic, EM extra(lepton-nuclear)
 - Decay, Radioactive Decay
 - Hadron elastic, hadron inelastic
 - Ion elastic and inelastic
 - Stopping of negatively charged particles
 - Step limiters (tracking cuts)
 - Optical
 - User may add custom constructor
- Physics List and its components are **unique objects**, which called in each thread two methods
 - G4VPhysicsConstructor::ConstructParticle()
 - G4VPhysicsConstructor::ConstructProcess()
 - Only const class members are allowed

- When your application has started and when the run manager has been initialized, you can:
 - Check the physics processes attached and their ordering:
 - `/particle/select e-`
 - `/particle/processes/dump`
 - Check what particles exist:
 - `/particle/list`
 - Check a particle property:
 - `/particle/select e-`
 - `/particle/property/dump`
 - Please type “help” to get the full set of commands for particle category


- Using UI interface Geant4 kernel change cuts and try to count number of steps in the same run
 - `/run/setCut 0.01 mm`
 - `/run/beamOn 100`
- Define cuts only for electrons
 - `/run/setCutForAGivenParticle e- 10 um`
 - `/run/setCutForRegion GasDetector 0.1 mm`
 - `/run/dumpCouples`
- How to change low-energy limit of production threshold
 - `/cuts/setLowEdge 0.1 keV`

- **G4PhysicsListHelper provides correct ordering for all processes from Geant4 libraries**
 - `G4PhysicsListHelper* helper = G4PhysicsListHelper::GetPhysicsListHelper();`
 - `helper->RegisterProcess(G4VProcess*, G4ParticleDefinition*);`
- **Custom process should be instantiated with defined ordering**
 - `G4ParticleDefinition* particle;`
 - `G4ProcessManager* man = particle->GetProcessManager();`
 - `man->AddDiscreteProcess(G4VDiscreteProcess*); // added to the end`
 - `man->AddProcess(G4VProcess*, idxAtRest, idxAlongStep, idxPostStep);`
- **Ownership of classes is not belonging to the Physics List class**
 - G4ParticleDefinition classes are static shared between threads
 - G4VProcess classes are registered in process thread local store
 - Model classes for EM and hadronic physics are also registered in thread local store
 - Hadronic cross sections are registered in another thread local store
 - All registrations are done automatically
- **All processes, models, and cross section classes should be instantiated via “new”**
 - Should not be included by object in any class


ELECTROMAGNETIC (EM) PHYSICS OVERVIEW

- Photon processes
 - γ conversion into e^+e^- pair
 - Compton scattering
 - Photoelectric effect
 - Rayleigh scattering
 - *Gamma-nuclear interaction in **hadronic sub-library** (**Bertini cascade**)*
- Electron and positron processes
 - Ionization
 - Coulomb scattering
 - Bremsstrahlung
 - *Nuclear interaction in **hadronic sub-library***
 - Positron annihilation
- Suitable for **HEP & many other Geant4 applications** with electron and gamma beams

HEP calorimeter



Medical linac




Located in \$G4INSTALL/sources/processes/electromagnetic

- **Standard**
 - γ , e up to 100 TeV
 - hadrons up to 100 TeV
 - ions up to 100 TeV
- **Muons**
 - up to 1 PeV
 - energy loss propagator
- **X-rays**
 - X-ray and optical photon production processes
- **High-energy**
 - processes at high energy ($E > 10 \text{ GeV}$)
 - physics for exotic particles
- **Polarisation**
 - simulation of polarised beams
- **Optical**
 - optical photon interactions
- **Low-energy**
 - Livermore library γ , e- from 10 eV up to 1 GeV
 - Livermore library based polarized processes
 - PENELOPE 2008 code rewrite , γ , e- , e+ from 250 eV up to 6 GeV
 - hadrons and ions up to 1 GeV
 - atomic de-excitation (fluorescence + Auger)
- **DNA**
 - Geant4 DNA modes and processes
 - Micro-dosimetry models for radiobiology
 - from 0.025 eV to 10 MeV
 - many of them material specific (water)
 - Chemistry in liquid water
- **Adjoint**
 - sub-library for reverse Monte Carlo simulation from the detector of interest back to source of radiation
- **Utils** : general EM interfaces and helper classes

- The uniform coherent approach for all EM packages
 - low energy and high energy models may work together
- A physical interaction or process is described by a process class
 - For example: G4ComptonScattering
 - Assigned to Geant4 particle types in Physics List
 - Three EM base processes:
 - G4VEmProcess
 - G4VEnergyLossProcess
 - G4VMultipleScattering
- A physical process can be simulated according to several models
 - each model being described by a model class
 - Naming scheme : « G4ModelNameProcessNameModel »
 - For example: G4LivermoreComptonModel
 - Models can be assigned to certain energy ranges and G4Regions
 - Inherit from G4VEmModel base class
- Model classes provide the computation of
 - Cross section and stopping power
 - Sample selection of atom in compound
 - Final state (kinematics, production of secondaries...)

- The scalability of Geant4 application in the MT mode depends on how effectively data management is performed
- Shared EM physics data:
 - tables for cross sections, stopping powers and ranges are kept by processes
 - Differential cross section data are kept by models
 - Material properties are in material data classes
 - EM parameters established for Physics Lists in the `G4EmParameters` class



Tables are filled by Master and have read-only access in run time

In this scheme number of threads is not limited

Gamma processes

- Photo-effect is the main process for absorption of low-energy gamma
 - Rayleigh scattering should not be neglected
- At high energy gamma conversion dominates
- Gammas may be absorbed by nuclei due to giant dipole resonance






Photo-electric effect – example of gamma process


In the photo-electric absorption process a **photon is absorbed** by an atom and an **electron is emitted** with an energy:

$$E_{\text{photoelectron}} = E_{\gamma} - B_{\text{shell}}(Z_i) \quad (1)$$

The atom, left in an excited state with a vacancy in the ionized shell, decays to its ground state through a cascade of radiative and non-radiative transitions with the **emission of characteristic x-rays** and **Auger and Coster-Kronig electrons**.



- At low energies ionisation dominates
- Above critical energy bremsstrahlung is the main process
 - Radiation energy loss exceeds ionization energy loss



EM PHYSICS CONSTRUCTORS

- A Physics list is the mandatory user class making the general interface between the physics the user needs and the Geant4 kernel
- List of particles: for which EM physics processes are defined
 - $\gamma, e^{\pm}, \mu^{\pm}, \pi^{\pm}, K^{\pm}, p, \Sigma^{\pm}, \Xi^{-}, \Omega^{-}, \text{anti}(\Sigma^{\pm}, \Xi^{-}, \Omega^{-})$
 - $\tau^{\pm}, B^{\pm}, D^{\pm}, D_s^{\pm}, \Lambda_c^{+}, \Sigma_c^{+}, \Sigma_c^{++}, \Xi_c^{+}, \text{anti}(\Lambda_c^{+}, \Sigma_c^{+}, \Sigma_c^{++}, \Xi_c^{+})$
 - $d, t, \text{He3}, \text{He4}, \text{Genericlon}, \text{anti}(d, t, \text{He3}, \text{He4})$
- The **G4ProcessManager** of each particle maintains a **list of processes**
- Geant4 provides several configurations of EM physics lists called **constructors** (**G4VPhysicsConstructor**) in the **physics_lists** library of Geant4
- These constructors can be included into a **modular Physics list** in a user application (**G4VModularPhysicsList**)

Geant4 standard EM Physics Constructors for HEP applications

- Description of Coulomb scattering (the same):
 - e^{\pm} : Urban - MSC model below 100 [MeV] and the Wentzel - WVI + Single scattering (mixed simulation) model above 100 [MeV]
 - muon and hadrons: Wentzel - WVI + Single scattering (mixed simulation) model
 - ions: Urban - MSC model
- But different MSC stepping algorithms and/or parameters: speed v.s. accuracy

Constructor	Components	Comments
<code>G4EmStandardPhysics</code>	Default: nothing or _EM0 (QGSP_BERT, FTFP_BERT,...)	for ATLAS and other HEP simulation applications
<code>G4EmStandardPhysics_option1</code>	Fast: due to simpler MSC step limitation, cuts used by photon processes (FTFP_BERT_EMV)	similar to one used by CMS; good for crystals but not good for sampling calorimeters (i.e. with more detailed geometry)
<code>G4EmStandardPhysics_option2</code>	Experimental: similar to option1 with updated photoelectric model but no-displacement in MSC (FTFP_BERT_EMX)	similar to one used by LHCb

Combined Geant4 EM Physics Constructors

- The primary goal is more the physics accuracy over the speed
- Combination of standard and low-energy EM models for more accurate physics description
- More accurate models for e^{\pm} MSC (Goudsmit-Saunderson(GS)) and more accurate stepping algorithms (compared to HEP)
- Stronger continuous step limitation due to ionisation (as others given per particle groups)
- Recommended for more accuracy sensitive applications: medical (hadron/ion therapy), space

Constructor	Components	Comments
<code>G4EmStandardPhysics_option3</code>	Urban MSC model for all particles	proton/ion therapy
<code>G4EmStandardPhysics_option4</code>	most accurate combination of models (particle type and energy); GS MSC model with Mott correction and error-free stepping for e^{\pm})	the ultimate goal is to have the most accurate EM physics description
<code>G4EmLivermorePhysics</code>	Livermore models for e^{-} , γ below 1 GeV and standard above; same GS MSC for e^{\pm} as in option4)	accurate Livermore based low energy e^{-} and γ transport
<code>G4EmPenelopePhysics</code>	PENELOPE models for e^{\pm} , γ below 1 GeV and standard above; same GS MSC for e^{\pm} as in option4)	accurate PENELOPE based low energy e^{-} , e^{+} and γ transport

EM Physics Constructors for testing of new models

Experimental Geant4 EM Physics Constructors

- Supposed to be used only by the developers for validations and model developments
- The main difference is in the description of the Coulomb scattering (GS, WVI, SS)

Constructor	Components	Comments
<code>G4EmStandardPhysicsGS</code>	standard EM physics and the GS MSC model for e^{\pm} with HEP settings	may be considered as an alternative to EM0 i.e. for HEP
<code>G4EmStandardPhysicsWVI</code>	WentzelWVI + Single Scattering mixed simulation model for Coulomb scattering	high and intermediate energy applications
<code>G4EmStandardPhysicsSS</code>	single scattering (SS) model description of the Coulomb scattering	validation and verification of the MSC and mixed simulation models
<code>G4EmLowEPPhysics</code>	Monarsh University Compton scattering model, 5D gamma conversion model, WVI-LE model	testing some low energy models
<code>G4EmLivermorePolarized</code>	polarized gamma models	a (polarized) extension of the Livermore physics models

USER INTERFACE TO EM PHYSICS

- EM parameters of any EM physics list may be modified at initialization of Geant4 using C++ interface to the **G4EmParameter** class or via UI commands
- Example of interfaces of G4EmParameters:
 - SetMuHadLateralDisplacement()
 - SetMscMuHadRangeFactor()
 - SetMscMuHadStepLimitType()
- Corresponding UI commands:
 - /process/msc/MuHadLateralDisplacement
 - /process/msc/RangeFactorMuHad
 - /process/msc/StepLimitMuHad
- Some other UI commands:
 - /process/em/deexcitationIgnoreCut true
 - /process/eLoss/UseAngularGenerator true
 - /process/em/lowestElectronEnergy 50 eV
 - /process/em/lowestMuHadEnergy 100 keV
 -

- Geant4 UI commands to define cuts and other EM parameters
- **G4EmCalculator**
 - easy access to cross sections and stopping powers (TestEm0)
- **G4EmParameters**
 - C++ interface to EM options alternative to UI commands
- **G4EmSaturation**
 - Birks effect (recombination effects)
- **G4ElectronIonPair**
 - sampling of ionisation clusters in gaseous or silicon detectors
- **G4EmConfigurator**
 - add models per energy range and geometry region
- **G4NIELCalculator**
 - Helper class allowing computation of NIEL at a step, which should be added in user stepping actions or sensitive detector (TestEm1)

How to extract Physics ?

- Possible to retrieve Physics quantities using a **G4EmCalculator** object
- Physics List should be **initialized**
- Example for retrieving the total cross section of a process with name **procName**, for **particle** and material **matName**

```
#include "G4EmCalculator.hh"
```

```
...
```

```
G4EmCalculator emCalculator;
```

```
G4Material* material =
```

```
    G4NistManager::Instance()->FindOrBuildMaterial(matName);
```

```
G4double density = material->GetDensity();
```

```
G4double massSigma = emCalculator.ComputeCrossSectionPerVolume  
    (energy,particle,procName,material)/density;
```

```
G4cout << G4BestUnit(massSigma, "Surface/Mass") << G4endl;
```

- A good example: **\$G4INSTALL/examples/extended/electromagnetic/TestEm0**
Look in particular at the **RunAction.cc** class

THANK YOU